


TC

MINIKing

MINI KING FLUX

FORD BRONCO BIG KAHUNA 4400



En Technical Guide

De Technischer Leitfaden

Fr Guide technique

Es Guía Técnica

Fi Tekninen Opas

No Teknisk Veiledning

Da Teknisk Vejledning

Sv Teknisk Guide

Pt Guia Técnico

It Guida Tecnica

Tr Teknik Kılavuz

Ro Ghid Tehnic

Pl Przewodnik Techniczny

Cs Technický Průvodce

Zh 技术指南

Ja 技術ガイド



hpi-racing

160807-006-SG

En: Further Information
De: Weitere Informationen
Fr: Informations complémentaires
Es: Más información
Fi: Lisätietoja
No: Mer informasjon
Da: Yderligere information
Sv: Mer information

Pt: Mais informações
It: Ulteriori informazioni
Tr: Daha fazla bilgi
Ro: Informații suplimentare
Pl: Dalsze informacje
Cs: Další informace
Zh: 更多信息
Ja: さらに詳しい情報

QS

En: Quick Start
De: Schnellstart
Fr: Démarrage rapide
Es: Inicio rápido
Fi: Pikakäynnistys
No: Rask oppstart

Da: Hurtig start
Sv: Snabbstart
Pt: Inicio rápido
It: Avvio rapido
Tr: Hızlı başlangıç
Ro: Pornire rapidă

Pl: Szybki start
Cs: Rychlý start
Zh: 快速入门
Ja: クイックスタート

**TG**

En: Technical Guide
De: Technischer Leitfaden
Fr: Guide technique
Es: Guía Técnica
Fi: Tekninen Opas
No: Teknisk Veiledning

Da: Teknisk Vejledning
Sv: Teknisk Guide
Pt: Guia Técnico
It: Guida Tecnica
Tr: Teknik Kılavuz
Ro: Ghid Tehnic

Pl: Przewodnik Techniczny
Cs: Technický Průvodce
Zh: 技术指南
Ja: 技術ガイド

**SG**

En: Startup Guide
De: Startanleitung
Fr: Guide de démarrage
Es: Guía de inicio
Fi: Käynnistysopas
No: Oppstartsguide

Da: Opstartsvejledning
Sv: Startguide
Pt: Guia de inicialização
It: Guida all'avvio
Tr: Başlangıç kılavuzu
Ro: Ghid de pornire

Pl: Przewodnik startowy
Cs: Průvodce spuštěním
Zh: 入门指南
Ja: スタートアップガイド

**RMI**

En: Radio Manual
De: Radiohandbuch
Fr: Manuel de la radio
Es: Manual de radio
Fi: Radiokäyttöopas
No: Radiobruksanvisning

Da: Radiobrugervejledning
Sv: Radiomanual
Pt: Manual do rádio
It: Manuale della radio
Tr: Radyo kılavuzu
Ro: Manual de utilizare radio

Pl: Instrukcja obsługi radia
Cs: Návod k použití rádia
Zh: 接收器说明书
Ja: 送信機取扱説明書

**EMI**

En: ESC Manual
De: ESC-Handbuch
Fr: Manuel ESC
Es: Manual ESC
Fi: ESC-käsikirja
No: ESC-manual

Da: ESC-manual
Sv: ESC-manual
Pt: Manual ESC
It: Manuale ESC
Tr: ESC Kılavuzu
Ro: Manual ESC

Pl: Instrukcja ESC
Cs: Manuál ESC
Zh: 电调手册
Ja: ESC取扱説明書

**UG**

En: User Guide
De: Benutzerhandbuch
Fr: Guide de l'utilisateur
Es: Guía del usuario
Fi: Käyttöopas
No: Brukerhåndbok

Da: Brugervejledning
Sv: Användarhandbok
Pt: Guia do utilizador
It: Guida utente
Tr: Kullanıcı Kılavuzu
Ro: Ghid de utilizare

Pl: Instrukcja użytkownika
Cs: Uživatelská příručka
Zh: 用户指南
Ja: ユーザーガイド



En: Scan Me
De: Scanne mich
Fr: Scanne-moi
Es: Escanéame
Fi: Skannaa minut
No: Skann meg

Da: Scan mig
Sv: Skanna mig
Pt: Escaneie-me
It: Scansionami
Tr: Beni Tara
Ro: Scanează-mă

Pl: Przeskanuj mnie
Cs: Naskenuj mě
Zh: 扫描二维码
Ja: スキャンして




En: Parts List
De: Stückliste
Fr: Nomenclature
Es: Liste des pièces
Fi: Osaluettelo
No: Reservedelsliste
Da: Deleliste
Sv: Reservdelslista

Pt: Lista de peças
It: Elenco dei componenti
Tr: Parça Listesi
Ro: Listă de piese
Pl: Lista części
Cs: Seznam dílů
Zh: 零件清单
Ja: 部品表

Parts #	Description	Parts #	Description
100864	Button Head Screw M2.5x4mm (Hex Socket/10pcs)	161181	Button Head Screw M2x8mm (Hex Socket/10pcs)
120298	Button Head Screw M2x6mm (Hex Socket/10pcs)	161182	Button Head Screw M2x10mm (Hex Socket/10pcs)
160817	Centre Transmission Gear Box Set	161183	Button Head Screw M2x12mm (Hex Socket/10pcs)
160830	HPI TF-706 6Ch Transmitter	161184	Button Head Screw M2x16mm (Hex Socket/10pcs)
160831	HPI RF-706 6Ch Receiver	161185	Button Head Screw M2x26mm (Hex Socket/10pcs)
160839	7.4V USB LiPo Balance Charger	161186	Flat Head Screw M1.7x6mm (Hex Socket/10pcs)
160860	HPI SD-02MGWR Micro Servo (6.0V/1.5kg/Metal Geared)	161187	Lock Nut M2 (Black/4pcs)
160864	Oil-Filled Shock Set V2 (Assembled/4pcs)	161189	Pin 1x5mm (Hex Socket/10pcs)
160868	Ford Bronco 4400 Grille Light LED	161190	Pin 1.5x6mm (Hex Socket/10pcs)
160870	Ford Bronco 4400 Bumper & Battery Tray Set	161192	Top Hat Bushing 4x3.4mm (4pcs)
160872	Ford Bronco 4400 Grille & Roof Light Parts Set	161193	Pivot Ball 4x6.8mm (10pcs)
160873	Ford Bronco 4400 Lens Set	161194	Pivot Ball 4x4.8mm (10pcs)
160879	Ford Bronco 4400 MT Driver Figure Set	161197	Ball Stud 4x9.7mm (10pcs)
160880	Tredz TRZ Tire 72x50/1.2in (2pcs)	161198	M2.5x3mm Set Screw (10pcs)
160881	MT-1 Wheel 1.2in (Blue/4pcs)	161199	M3x3mm Set Screw (10pcs)
160882	MT Hex Hub Set	161213	Ford Bronco 4400 Roll Cage (Grey)
160883	MT Chassis Set (Grey)	161214	Transmission Gear Set
160884	MT Suspension Link Set (Blue)	161215	Gear Differential Set (Assembled/1Set)
160885	MT Sway Bar Link Set	161216	Diff Rebuild Kit
160886	Servo Saver Set	161217	Diff Output Cup 7x15.8mm (2pcs)
160889	Ford Bronco 4400 Painted Body - Big Kahuna	161218	Cup Joint 9x15mm (2pcs)
160891	Aluminum Chassis Brace Set (Orange)	161219	Complete Ball Bearing Set (Mini King)
160892	Center Gear Box Shaft Set (Single Speed)	161220	Flat Head Screw M1.4x5mm (10pcs)
160893	HD Steel Center Drive Shaft Set	161221	Flat Head Screw M2x6mm (Hex Socket/10pcs)
160894	HD Front CVD Drive Shaft Set	161222	Button Head Screw M1.7x12mm (Hex Socket/10pcs)
160895	HD Rear Drive Shaft Set	161223	Button Head Screw M2x14mm (Hex Socket/10pcs)
160896	Aluminum 7mm Hex Hub Set (Orange/4pcs)	161224	Button Head Screw M2x18mm (Hex Socket/10pcs)
160898	FLX16-3S30-WP Flux ESC with XT-30	161226	Cap Head M2x6mm (Hex Socket/10pcs)
160899	FLX16-2435-4500KV Brushless Motor	161227	Flange Lock Nut M2.5 (Silver/4pcs)
161125	Axle Housing Set	161228	Screw Shaft M2x12mm (Hex Socket/10pcs)
161126	Steering Spindle & Hub Set	161238	Shock Spring 10x33x0.6mm 14.5 Coils (Medium)
161127	Steering Link & Diff Case Set	161247	Plazma 7.4V 800mAh 35C LiPo Battery Pack
161128	Differential Bevel Gear Set (44T/18T/0.5M)	161249	Pinion Gear 10T (0.5M / 2.3mm)
161129	Differential Gear Set (18T/10T)	161258	Flat Head Screw M1.4x9mm (10pcs)
161171	Shock Rebuild Set	161259	CVD Driveshaft Rebuild Kit (Mini King)
161177	Button Head Screw M1.7x5mm (Hex Socket/10pcs)		
161178	Button Head Screw M1.7x7mm (Hex Socket/10pcs)		
161179	Button Head Screw M1.7x10mm (Hex Socket/10pcs)		
161180	Button Head Screw M2x4mm (Hex Socket/10pcs)		


En: Exploded Views
De: Explosionszeichnung
Fr: Vue éclatée
Es: Vista explosionada

Fi: Räjätyskuva
No: Sprengskisse
Da: Eksploderet visning
Sv: Exploderad vy



Pt: Vista explodida
It: Vista esplosa
Tr: Patlatılmış Görünüm
Ro: Vedere explodată

Pl: Widok rozłożony
Cs: Rozłożený pohled
Zh: 爆炸图
Ja: 分解図




3-1

En: Body Assembly
De: Karosseriebaugruppe
Fr: Assemblage de la carrosserie
Es: Ensamblaje de la carrocería
Fl: Koriokokoonpano
No: Karosserimontering
Da: Karrosserisamling
Sv: Karossmontering

Pt: Montagem da carroceria
It: Assemblaggio della carrozzeria
Tr: Gövde montajı
Ro: Ansamblu caroserie
Pl: Zespół nadwozia
Cs: Sestava karoserie
Zh: 车身组件
Ja: ボディアセンブリ


En: Main Components
De: Hauptkomponenten
Fr: Composants principaux
Es: Componentes principales


Fi: Pääkomponentit
No: Hovedkomponenter
Da: Hovedkomponenter
Sv: Huvudkomponenter




Pt: Componentes principais
It: Componenti principali
Tr: Ana bileşenler
Ro: Componente principale

Pl: Głównie komponenty
Cs: Hlavní komponenty
Zh: 主要组件
Ja: 主要部品











3-4

En: Front Axle Assembly
De: Vorderachse-Montage
Fr: Assemblage de l'essieu avant
Es: Montaje del eje delantero
Fi: Etuakselin kokoonpano
No: Forakselmontering
Da: Forakselsamling
Sv: Framaxelmontering

Pt: Montagem do eixo dianteiro
It: Assemblaggio dell'asse anteriore
Tr: Ön aks montajı
Ro: Asamblare axă față
Pl: Montaż osi przedniej
Cs: Montáž přední nápravy
Zh: 前轴组裝
Ja: 前軸組立









3-6

En: Shock Assembly
 De: Stoßdämpfer-Montage
 Fr: Assemblage de l'amortisseur
 Es: Montaje del amortiguador
 Fl: Iskunjaimennin kokoonpano
 No: Støtdempermontering
 Da: Støddæmper samling
 Sv: Støtdämparmontering



Pt: Montagem do amortecedor
 It: Assemblaggio dell'ammortizzatore
 Tr: Amortisör montajı
 Ro: Asamblare amortizor
 Pl: Montaż amortyzatora
 Cs: Montáž tlumiče
 Zh: 缓冲器组装
 Ja: ショックアセンブリ





Pt: Montagem da transmissão
 It: Assemblaggio della trasmissione
 Tr: Şanziman montajı
 Ro: Ansamblu transmisie

Pl: Zespół skrzyni biegów
 Cs: Sestava převodovky
 Zh: 变速器组件
 Ja: トランスミッションアセンブリ





HPI RACING A/S
www.hpiracing.com
HPI Racing A/S
Jegindøvej 21
DK - 8800 Viborg
Denmark
Email: info@hpiracing.com

Serial Number
Seriennummer
Numéro de série
シリアルナンバー

