








FTX HAVOK EXPLODED PARTS DIAGRAM

SHOCK ASSEMBLY





Rotate this ring to adjust spring tensions for desired suspension travels.



FTX10626



DIFF. ASSEMBLY



STEERING ASSEMBLY




SERVO LINK ASSEMBLY




FTX HAVOK EXPLODED PARTS DIAGRAM

CENTER SHAFT ASSEMBLY





INSTALLING THE STEERING COMPLETE TO THE CHASSIS





FTX HAVOK EXPLODED PARTS DIAGRAM

INSTALLING THE DIFF.
COMPLETE INTO THE CHASSIS





INSTALLING THE CENTER
DRIVE TRAIN INTO THE CHASSIS




FTX HAVOK EXPLODED PARTS DIAGRAM

INSTALLING THE SERVO TO THE CHASSIS






INSTALLING THE REAR GEAR BOX TOP HOUSING TO THE CHASSIS





FTX HAVOK EXPLODED PARTS DIAGRAM

INSTALLING THE UPPER DECK TO THE CHASSIS




INSTALLING THE MOTOR TO THE CHASSIS




FTX HAVOK EXPLODED PARTS DIAGRAM

INSTALLING THE MOTOR GUARD TO THE CHASSIS




FRONT SUSPENSION ASSEMBLY






FTX HAVOK EXPLODED PARTS DIAGRAM


REAR SUSPENSION ASSEMBLY



FRONT/REAR SKID PLATES




REAR SHOCK TOWER






FTX HAVOK EXPLODED PARTS DIAGRAM

FRONT SUSPENSION INSTALLATION




REAR SUSPENSION INSTALLATION





FTX HAVOK EXPLODED PARTS DIAGRAM


INSTALLING THE SHOCKS






FTX HAVOK EXPLODED PARTS DIAGRAM

INSTALLING THE WHEELS





INSTALLING THE SWITCH MOUNT





FTX HAVOK EXPLODED PARTS DIAGRAM


INSTALLING THE FRONT BODY POST PADS






FTX HAVOK EXPLODED PARTS DIAGRAM

INSTALLING THE ROLL CAGE TO THE BODY





FTX HAVOK PARTS LISTING

FTX10600	FTX10601	FTX10602	FTX10603
 Chassis	 Upper Deck+Rear Gear Box Top Housing+Motor Guard	 Front and Rear Shock Towers+Body Posts	 Front Upper Suspension Arms (Left/Right)
FTX10604	FTX10605	FTX10606	FTX10607
 Front Lower Suspension Arms (Left/Right)	 Rear Lower Suspension Arms (Left/Right)	 Rear Upper Links (L/R) Steering Links (L/R) Servo Link	 Bumpers (Fr./Rr)
FTX10608	FTX10609	FTX10610	FTX10611
 Servo Top Plate+Motor End Braces	 Steering Post Assembly	 Servo Saver Assembly +Switch Mount	 Diff. Assembly
FTX10612	FTX10613	FTX10614	FTX10615
 Diff. Complete(Fr./Rr.)	 Spur Gear+ Drive Pinions	 Steering Hubs (L/R)	 Rear Hubs (L/R)
FTX10616	FTX10617	FTX9715	FTX9735
 Roll Cage + Wing	 Front/Rear Drive Shafts	 Diff. Outdrive Cups	 Motor Heat Sink






FTX HAVOK PARTS LISTING

FTX10618  Slick Wheels Complete(2P)	FTX10619  Center Drive Shaft	FTX10620  Diff. Cup Posts (4P)	FTX10621  Diff.Pins(8P)
FTX10622  Front Upper Arm Hinge Bolts 3x28mm(4P)	FTX10623  Wheel Hub Pins 4P (φ2.5*23mm)	FTX9745  Ball Bearings 8P (φ7.93*12.7*3.95mm)	FTX9746  Ball Bearings 8P (φ6.35*9.53*3.17mm)
FTX9723  Front/Rear Lower Arm Hinge Pins 2.5*42mm(4P)	FTX9727  Steering Posts 4P	FTX9729  Perforated Balls 8P (φ5.8mm)	FTX10624  Steering Hub Screws 4P (2.8*5.5mm)
FTX10625  Perforated Step Balls 6P (φ4.8mm)	FTX10626  Front /Rear Shocks 2P	FTX9738  Transmitter	FTX10627  Motor 390
FTX10628  3-wire 2.2Kg Servo	FTX10629  ESC/Receiver (w/Gyro)	FTX9734  Motor Pinion (14T)+Set Screw (brush motor only)	FTX10630  Li-ion Battery 7.4V,1500mAh





FTX HAVOK PARTS LISTING

FTX9743  Wheel Hex. (8P)	FTX9744  Zip Ties (8P)	FTX9737  USB Charger	FTX9741  Battery Binding Strap
FTX9760  Body Clips (4P)	FTX9747  Wheel Lock Blots(8P)	FTX10631BL  Blue Pickup Drift Car Truck	FTX10631Y  Green Pickup Drift Car Truck
FTX10632  Chassis Side Lights & Gyro Unit	FTX6766  Countersunk Self Tapping Screws(12P) KBHO 2.6x8mm	FTX10645  Pan Head Mechanical Screws (12P) BMHO2.5x14mm	FTX9749  Pan Head Self Tapping Screws (12P) PBHO2.6x10mm
FTX10646  Countersunk Self Tapping Screws(12P) KBHO 2.3x10mm	FTX7289  Countersunk Self Tapping Screws(12P) KBHO 2.6x6mm	FTX7290  Countersunk Self Tapping Screws(12P) KBHO 2.6x12mm	FTX8618  Pan Head Self Tapping Screws (12P) BBHO2.6x6mm
FTX9752  Set Screws (12P) M2.5*2.5mm	FTX7284  Flange Head Self Taping Screws (12P) PWTFO 2.6*10mm	FTX7296  Pan Head Self Tapping Screws (12P) BBHO2.6x8mm	FTX10647  Pan Head Self Tapping Screws (12P) BBHO2.3x10mm



FTX HAVOK PARTS LISTING & OPTION PARTS

FTX10645	FTX9757	FTX9758	FTX10649
 Countersunk Self Tapping Screws (12P) KBHO 2x12mm	 Countersunk Self Tapping Screws (12P) KBHO 2.3x12mm	 Flange Head Self Taping Screws (12P) PWTHO 2.6*12mm	 Pan Head Mechanical Screws (12P) BMHO3x15mm
FTX10650	FTX10690	FTX10691	
 Pan Head Fine Thread Screws (12P) BMHO2.5x10mm	<u>OPTIONAL PART</u>  Cast Metal Diff. Complete (Metal Cups)	<u>OPTIONAL PART</u>  Cast Metal Pinions+ Spur Gear	
STREET BODY SPARE PARTS			
FTX10633Y	FTX10633BL	FTX10634	FTX10635
 Body (Blue)+Body Decal	 Body (Green)+Body Decal	 Front Vent Mask	 Headlight Brace/Taillight Brace
FTX10636	FTX10637		
 Taillight Covers	 Headlight /Taillight		